

OneFabric Scissor Section Replacement Instructions

1. Remove rivets from display, trick to removal is to pull the rivet left from right and keep working it and it will come out (this may take a little bit)
2. Once the rivets are out and the bad scissor section removed you want take the replacement scissor section and line it up to the scissor section right next to it
3. Once the replacement scissor section is lined up you will screw in the 4 replacement screws